©2014 HMDX. All Rights Ro



CRAZE BUDS QUICK START GUID









- Snap ear hooks into place
 Position cord behind your neck
 If the cord length is not comfortable, use the cable clip to adjust it.
 Secure ear hook behind your ear
 Place earbud in ear
 Repeat for both earbuds
 Press and hold the U button for 3 seconds
 Follow instructions on your device to pair the unit
 Pair your device with the earbuds by selecting HMDX Craze from the Bluetooth listings on your device or selecting YES
 Press play on your device and use the controls on the unit to adjust desired volume

HEY. HAVE WE SEEN YOU HERE BEFORE?

Register your earbuds at www.hmdxaudio.com. Information about where you bought them and how you're using them is like gold for the people who make these earbuds. Do them a solid, will ya?

Por manual de instrucciones e información de garantía en español visítenos en www.hmdxaudio.com.

There are lots of cool HMDX speakers. Check them all out at www.hmdxaudio.com

Setup is pretty easy, but we put a manual together just in case you need it. It's full of information and sarcasm—just like that English teacher you had that crazy

PACKAGE CONTENTS













User Manual JUST CHARGE IT

Charging the earbuds is so easy you've probably figured it out by now, but just in case, you've got two options: you can charge them using your computer or a wall outlet.

1. The cord that came with the earbuds -the one with the USB on one end and the Micro USB on the other—will work with your computer.

2. If you want to use the wall outlet, you'll need to pick up a power cord with a Micro USB the next time you're at the store, or use any USB AC adapter, including the one for your cell.



Plug them in and your earbuds will be ready for an epic night in no time. You should go get ready, too! They need about 3 hours for 6 hours of party time.

CONTROL YOUR DESTINY. OR AT LEAST YOUR EARBUDS

- This is the power button, press and hold for 2–3 seconds to power on.
- 2. Turn the music up. (Press and hold for 2
- seconds to skip to the next track.) 3. Push it to play, push it again to paus
- Turn the music down. (Press and hold for 2 seconds to move to the previous track.)
- 5. This light lets you know when your device is charging and when Bluetooth is connected.
- The power cord goes here.
- Cable clip to adjust strap. To shorten pull the cable through the clip to the desired length.



BLUETOOTH® CONNECTION: IT'S A SETUP

Like any amazing couple, this one starts with a connection—one between your device and the earbud's Bluetooth

Here's how it works:

- We know you're probably going to think, "derp" with this one, but we have to say it: Make sure the smartphone, tablet or computer you want to hook up to the earbuds has *Bluetooth*. (There. We got that out of the way.)
- Turn on the earbuds and look for the little blinking light.
- 3. Do whatever your device needs you to do on its end. (We don't know what you're using. We're not spies.)
- Look HMDX Craze in your fo device's Bluetooth list or click pops up on your deviceand BAM you're connected.
- Now hit PLAY on your earbuds and crank it up-or down if you're lame

You're probably only going to have to do this once, unless your device goes through a major I-just-dropped-it-in-the-pool kind of reboot. The device and Bluetooth will find each other every time just as long as the earbuds are set to Bluetooth and your device's Bluetooth is; you know—on.

If you're connecting to a computer, you may have some extra steps on that end. You'll have to get that information from the computer company.

Depending on your device you may be prompted to enter a pairing code. If prompted enter "0000" as the code.

If you are having trouble pairing, you can manually enter paring mode. Just press and hold the power button for 5 seconds when the Craze Earbuds are powered off.

Note: If you turn on your Craze Earbuds but haven't started the party, they will automatically power off after 2 minutes of unpaired inactivity.

ALLOW US TO SHED SOME LIGHT

	What It Looks Like	What it Means
CHARGE	Flashing Red	Low Battery
	Red (when plugged in)	Charging
	Light turns off (while plugged in)	Fully Charged
*	Quick Blue Flash	Reconnect Mode
	Slow Blue Flash	Connected
	Quick Blue/Red Flashing	Pairing Mode



HELLO? SPEAKERPHONE? YES!

When friends call to interrupt your party of one—and you know they will—answ the phone without disconnecting from your HMDX Craze. Yes, that's right. Your earbuds are a speakerphone too. How amazing is that?

Here's how it works:

- 1. Make sure your phone and earbuds are connected through Bluetooth
- 2. Answering and ending a call works the same way: simply click the PLAY/PAUSE button on your Craze.
- 3. If you'd rather not talk, hold down the PLAY/PAUSE button on your Craze for three seconds to ignore the call.

THE COOLEST PART: The Craze knows when a call is coming in and pauses the music before ringing. When you hang up, the music starts where it left off—and so does the party. If it's you making the call, just start dialing from your phone, and the Craze automatically does its hands-free thing. Isn't it refreshing to know your earbuds totally get you?

Note: If your Craze Earbuds are connected to a smart phone, you can talk to Siri (or any other voice control assistant). Just hold down the PLAY/PAUSE button and Voila!

A PERFECT FIT

- Put the buds in your ears with the strap behind your neck (trust us, no one looks good with the strap in front) to see if the length is comfortable.
- If the fit is too loose or too firm, adjust strap by placing tension on the portion of the strap that is to the left of the cable clip. Do that and a loop will magically form in the middle of the cable clip. Now, pull the strap in a downward motion on the right side of the cable clip. Continue with this process until the strap is the length you want and feels good.

COMING CLEAN

A soft, dry towel is all you need to clean off your earbuds. Using water, harsh cleaners or anything else only starts messing with the mechanics inside. So, yeah, don't do it.

STUFF THE GOVERNMENT MAKES US SAY

FCC Disclaimer:

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by HMDX could void the

user's authority to operate this equipment ONE YEAR LIMITED WARRANTY

For detailed Warranty Instructions and Information visit:

http://www.hmdxaudio.com/customer-support/warranty-1yr

To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-753-3000 or email cservice@hmdxaudio.com for assistance.:Please make sure to have the model number of the product available. Representatives are available 8:30am - 7:00pm

EST Monday-Friday STUFF OUR LAWYERS MAKE US SAY

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed,

including the following: READ ALL INSTRUCTIONS BEFORE USING

- WARNING: To avoid hearing damage, make sure that the volume on your
- device is turned down before powering on your earbuds.
 Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to Smartphones, iPod/MP3
- player or any other device. Do not place or store this product where it can fall or be dropped into a tub
- or sink Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOTA TOY.

 Never operate this product if it has a damaged cord, plug; cable or housing:

 - Keep away from heated surfaces.
 Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents

A MESSAGE FROM THE ENVIRONMENT

WARNING:

This product has an internal, non-replaceable lithium battery. Please dispose in accordance with your local state, province and country guidelines.

This product contains small parts that may pre children

CAUTION: All servicing of this product must be performed by authorized HMDX Service Personnel only

Note: The most up-to-date version of the HMDX Craze Earbuds User Guide can



Por manual de instrucciones e Inform